



Getting Started




1. Power up the motor by plugging in the USB-C power supply into the **(2)** USB-C port

Getting Started



2. You may press and hold the **(1)** Move Button to spin the **(4)** Rotating shaft clockwise

Getting Started



3. Double-click the **(1)** Move Button to change the rotating direction of the shaft

Note that the motor rotates at a fixed speed, but can be modified using the MvIt Now mobile app


(1) Move Button

(2) USB-C port

(3) Status LED

(4) Rotating shaft

Getting Started



4. The **(3)** Status LED will slowly blink green until it is paired via the Mvlt Now mobile app

After pairing the motor with the app the first time, the **(3)** Status LED should stay lit solid green as long as a WiFi connection is available

Getting Started

5. Download the MvIt Now app on your Android or Apple smartphone

Android



<https://play.google.com/store/apps/details?id=com.mvitnow.mvit>

Apple iOS



<https://apps.apple.com/ca/app/mvit-now/id1557064154>

Getting Started

6. Open the app, sign in or create an account
7. Add your motor device using the “+” button on the top-right
8. Follow the instructions on the app

